




# Regency Round Gazebo Two Tone Mocha 3.5M

(CAM0439)

A x 6



B x 1




C x 6



D x 6




E x 6




F x 6



G x 1



G1 x 6




H x 12




GROUND PEG

L1 x 24




L2 x 24





N x 24



L x 6









K x 2









**Note:**

- 1.This gazebo requires a minimum of 2 people for assembly.
- 2.For safety, when building the gazebos, step ladders should be used when working above ground level.
- 3.In the unlikely event that any components are either damaged or missing, please return the complete item to the retail outlet from where it was purchased. This does not affect your statutory rights.



Note: This item is intended as a sunshade and should not be left out during high winds as it could be damaged. It is recommended to remove the curtains and roof canopy when not in use. Although tent pegs are supplied, it is recommended the frame be screwed down to decking or patio if it is to be left out.



Note: This item is intended as a sunshade and should not be left out during high winds as it could be damaged. It is recommended to remove the curtains and roof canopy when not in use. Although tent pegs are supplied, it is recommended the frame be screwed down to decking or patio if it is to be left out.